




		-			E۸
	AUTHENTICATION FAILED ACCESS DENIED TO CS  BERVER  AUTHENTICATION FAILED ACCESS DENIED TO CS  BERVER  SERVER  SERVER  SCACE  SCA		120		LENT SHEET
	USER CONNECTS TO CENTRAL SERVER 10  CENTRAL SERVER SENDS APPLET FOR LOGIN 12		210		
DESKTOP		CONTROL SERVER		EQUIPMENT DIAGNOSTIC MONITOR	3/
	REPORT INFO AND REQUESTS SENT BACK AND FORTH USER CHOOSES IDM TO CONNECT TO 18	<del></del>	IDM SENDS APPLET FOR LOGIN	- Docket	"SECUI
	BROWSER LAUNCED FOR IDM CONNECTION 20	25	25 LOGIN INFO SENT TO IUM SERVER AUTHENTICATION SUCCEEDED	No. 390	rich Fasi
	LOGIN INFO TO iDM 24 USER REQUESTS SENT TO iDM 26		REPORT INFO SENT TO PC AUTHENTICATION FAILED	P010777-U	OTE DIAGI tvold. Rog
	AUTHENTICATION FAILED		ERROR DIALOG DISPLAYED ON UI	JS (PAR)	er
	ERROR DIALOG DISPLAYED ON UI				,
/ 200			FIG. 3	:	







205-

182

510,

160-

